

Australia

FF895HS

Cordless display & call waiting compatible cordless handset

This handset and charger
is for use only with the FF895
cordless telephone system.

THUNDERSTORM WARNING

It is recommended that you disconnect your telephone during a thunderstorm as you can get a shock from your telephone (and other electrical appliances). We recommend you follow these simple precautions during a thunderstorm:

- Do not use your telephone unless the call is urgent.
- If you must use your telephone, make the call as brief as possible and keep clear of electrical equipment and metal fixtures.
- Do not stand in bare feet on uncovered concrete floors.
- Do not touch brick or concrete walls.

CLEANING

The case should be cleaned by wiping with a damp cloth.

- Do not use abrasives, solvents or spray polish that may enter through holes in the earpiece and mouthpiece and cause damage.
- Do not place the telephone in direct sunlight or use in extreme humidity.
- Clean the display with a soft dry cloth. Do not push on the display, it can be damaged.
- The battery contacts on the charger pod and the handset should be cleaned regularly, ie. every 2 months with a pencil eraser and/or a dry soft cloth.

GUARANTEE

If you believe your FF895HS is malfunctioning, please consult the troubleshooting section of the FF895 manual and ensure that you have followed the instructions.

The FF895HS is guaranteed for a period of 12 months from the date of purchase. In the unlikely event of a fault during this period, please return it with a copy of the purchase receipt to:

DORO Australia Pty Ltd
13 Columbia Way, Norwest Business Park
Baulkham Hills NSW 2153 Australia
Phone (02) 8853 8444 Fax: (02) 8853-8489
Email: helpline@doroaus.com

Audioline products are distributed in New Zealand by Atlas Gentech. For enquiries and assistance call their Consumer Helpline (Toll Call) 0900 50025.

NOTE: The guarantee does not extend to damage caused by misuse, negligence, excessive voltage, faults on the telephone line or lightning. This guarantee in no way affects your statutory rights. DORO is the trademark of DORD AB.

User guide

AUDIOLINE®

IMPORTANT

The caller display service requires a subscription to your Network operator.

BATTERY CHARGING

① FIT HANDSET BATTERY

Fit battery, ensuring RED wire is on left hand side.

REPLACE BATTERY COVER by sliding into locking hole on handset, ensuring you do not trap the battery wires.

② CHARGE HANDSET BATTERY

CONNECT the charger pod to the mains, using the power adaptor provided.

FIT the aerial to the handset and PLACE the handset in the charger pod.

LEAVE TO CHARGE FOR 14 HOURS WITHOUT INTERRUPTION.

The pod does not require connection to the telephone line.

HANDSET REGISTRATION

After charging and before use, this handset **MUST** be registered with the main base unit, otherwise it will not function correctly.

Please follow the procedure below:

③ NEW HANDSET & ORIGINAL BASE UNIT

1. Ensure the handset has been properly charged.
2. Place the new handset onto the original BASE UNIT.
3. The handset display will now change from "No Access!!" to "Setup..."
4. If communication between handset and base unit was successful a long beep tone will be heard and the display will show "Setup OK".
5. You will now be prompted to setup the handset identification number. The display shows "Enter HS no"
6. Press button 1-4 to select the handset identification number.
7. The handset display will now show "RingerOn #2" (example).

If the communication fails at Step 4, there will be an error tone of three beeps and the display will show "Setup fail" and will return to the "No Access!!" display. Should this occur lift the handset off the BASE UNIT and then replace it. Now repeat Steps 3-7 above.

NOTE: Do not use the same handset identification number for different handsets.

WARNING

The FF895HS can only be supplied power by an Audioline power adaptor PA894 (Approval No. N/12461).

In the event of a mains power failure it will not be possible to dial 000 or the emergency services numbers. An alternative line powered telephone should be used in this case.

Do not install your telephone in damp or high humidity locations, such as a laundry or bathroom. If any damage is caused by such elements it is not covered by the manufacturers warranty.