












SENSOR 500 INITIAL SETUP

On pages 5 & 6 of this manual, references to the display showing: "-----" should read: display showing "INSERT 10/0"

If you are a Centrex user, the phone needs to be programmed to insert "10"
If you are not using Centrex, the phone must be set to insert "0"

- Press  and hold until display shows: "INSERT 10/0".
- Press  to select.
- Press  to select "0" or "10" (current selection will flash).
- For Centrex "10" must be flashing.
- For Non-Centrex "0" must be flashing.
- Press  to set.

When you first connect your Sensor 500 and are using Telecom Call Minder service you will need to program the PLAY button.

- Press 
- Press and hold down  until the display shows text, then release
- Dial 083210.
- Press 
- Dial your call minder PIN number. (Please note that this number will show on the display each time the  key is pressed.)
- Press #
- Press 
- Dial "1"
- Press  to store
- Press  to finish.